HLVA6I23

Single-Phase Monitor



Description


The HLVA6I23 is a single-phase undervoltage monitor designed to protect sensitive equipment from brownout or undervoltage conditions. Time delays are included to prevent nuisance tripping and short cycling. The 30A, 1hp rated, SPDT relay contacts allow direct control of motors, solenoids and valves. The output relay can be ordered with isolated SPDT contact to allow monitoring of one voltage and switching a separate voltage. Two undervoltage trip point ranges allow monitoring of 110 to 120VAC or 208 to 240VAC systems.

Operation

Upon application of input voltage the output relay remains de-energized. When the input voltage value is above the pull-in voltage, the restart delay begins. At the end of the restart delay, the output relay energizes. When the input voltage falls below the trip point, the trip delay begins. If the input voltage remains below the pull-in voltage for the entire trip delay the relay de-energizes. If the input voltage returns to a value above the pull-in voltage, during the trip delay, the trip delay is reset and the relay remains energized. If the input voltage falls below the trip point voltage during the restart delay, the delay is reset and the relay remains de-energized. Reset is automatic upon correction of an undervoltage fault.

Reset: Removing input voltage resets the output relay and the time delays.

Wiring Diagram



V = Voltage
NO = Normally Open
NC = Normally Closed
C = Common
T1 = Undervoltage Trip Point
T2 = Restart Delay

Features

- 30A, SPDT, NO output contacts
- 100 to 240VAC input voltage
- 70 to 220VAC adjustable undervoltage trip point in 2 ranges
- Restart delays from 3 - 300s
- Trip delay 1 - 20s fixed
- Isolated or non-isolated relay contacts

Accessories



P1015-13 (AWG 10/12), **P1015-64** (AWG 14/16) **Female Quick Connect**
These 0.25 in. (6.35 mm) female terminals are constructed with an insulator barrel to provide strain relief.



P1023-6 Mounting bracket
The 90° orientation of mounting slots makes installation/removal of modules quick and easy.



P1015-18 Quick Connect to Screw Adapter
Screw adapter terminal designed for use with all modules with 0.25 in. (6.35 mm) male quick connect terminals.



C103PM (AL) DIN Rail
35 mm aluminum DIN rail available in a 36 in. (91.4 cm) length.



P1023-20 DIN Rail Adapter
Allows module to be mounted on a 35 mm DIN type rail with two #10 screws.

© 2016 Littelfuse Protection Relays & Controls


HLVA6I23

Specifications

Input

Min & Max RMS Voltage	70 to 264VAC		
AC Line Frequency	50/60 Hz		
Power Consumption	AC ≤ 4VA		
Undervoltage Sensing			
Type	Peak voltage sensing		
Ranges			
(4)	70 to 120VAC		
(6)	170 to 220VAC		
Pull-In Voltage	105% or trip point voltage		
Trip Point Accuracy	± 3% of trip point		
Time Delay			
Restart Delays	3 - 300s adjustable		
Trip Delay	1 - 20s fixed in 1s increments		
Repeat Accuracy	±0.5% or 20ms, whichever is greater		
Tolerance (Factory Calibration)	±5%		
Reset Time	≤ 150ms		
Time Delay vs. Temp. & Voltage	≤ ±10%		
Output			
Type	Electromechanical relay		
Form	SPDT		
Ratings		**SPDT-NO**	**SPDT-NC**
General Purpose	125/240VAC	30A	15A
Resistive	125/240VAC	30A	15A
	28VDC	20A	10A
Motor Load	125VAC	1 hp*	1/4 hp**
	240VAC	2 hp**	1 hp**
Life	Mechanical - 1 x 10^6		
	Electrical - 1 x 10^5, *3 x10^4, **6,000		
Protection			
Surge	IEEE C62.41-1991 Level A		
Circuitry	Encapsulated		
Isolation Voltage	≥ 1500V RMS input to output; isolated units		
Insulation Resistance	≥ 100 MΩ		
Mechanical			
Mounting	Surface mount with one #10 (M5 x 0.8) screw		
Dimensions	**H** 76.7 mm (3"); **W** 51.3 mm (2"); **D** 38.1 mm (1.5")		
Termination	0.25 in. (6.35 mm) male quick connects		
Environmental			
Operating/Storage Temperature	-40° to 60°C / -40° to 85°C		
Humidity	95% relative, non-condensing		
Weight	≅ 3.9 oz (111 g)		

Function Diagram



tr = Restart Delay
td = Trip Delay
PI = Pull-in 105% or trip point
TP = Trip Point
V = Monitored Voltage
IV = Input voltage
C-NO = Normally Open Contacts
C-NC = Normally Closed Contacts

© 2016 Littelfuse Protection Relays & Controls