



Battery Disconnects



Low Current Battery Switches

Littelfuse Part #	Description
08098700	100A Battery Disconnect - Removable Handle
08099080	150A Battery Disconnect - Removable Handle w/Boot

Push-to-Off Switch

Littelfuse Part #	Description
08098400	250A Battery Disconnect - Push Button

310A M-750 Battery Selector Switch

Littelfuse Part #	Description
M-750	310A Battery Selector Switch

300A SR Series Switches

Littelfuse Part #	Description
880062	300A Master Battery Disconnect - Panel Mount
880064	300A Master Battery Disconnect Surface Mount w/Lockout

300A 75920 Series Switches

Littelfuse Part #	Description
75920	300A Master Battery Disconnect Panel Mount w/Lockout
75920-01	Master Disconnect Panel Mount w/Lockout and Yellow Handle

500A Dual-Pole TR Series Switches

Littelfuse Part #	Description
880175	500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout
880175-0001	500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout and Red Handle
880175-0002	500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout and Yellow Handle

Metal Body Switches

Littelfuse Part #	Description
2484	175A Battery Disconnect - Lever
75908	300A Battery Disconnect - Lever
75907	300A Double Pole Battery Disconnect